



X

Y

Z

A

UX + C1 JX

UY + C2 JY

UZ + C3 JZ

UA + C4 JA

RP2040 R1 C6

R2 J1 R3

ENDSTOP X1 X2 Y1 Y2 Z1 Z2 J01 J02 J03 J04

C7 C8 C9 C10

R4 R5 Q1 D1 R6 R7 Q2 D2 R8 R9 Q3 D3 R10 R11 Q4 D4

GND

+12V

04 + 03 + 02 + 01